

ROCK SOCCER- JD MOWER DIRECTIONS

1. Clean the radiator- 2 clips behind seat release rear lid- tilts back- cleanout grass
(check gap between top edge and also the radiator itself)
2. Check for grass buildup on top of decks, under carriage.
3. Fuel- DIESEL (red cap of mower)- there are 2 Diesel cans in barn, can fill at the Shell station- furthest pump from the building has a smaller nozzle that fits yellow cans- save receipts.
4. Check fluids- oil, coolant, etc. Grease periodically.
5. Brake- left peddle, Forward- center peddle, Reverse- right peddle
6. Will run only if you are in the seat. Start mower.
7. Black handles- controls the lift on the 3 decks.
8. Decks lock when lifted- red lock switch. Must lean over and release before lowering.
9. Make sure yellow knob is down to start. Lift & hold up to start blades moving after running.
10. Engine Throttle- run about the middle. Will have to increase if long, but use less peddle if bogging down.
11. Travel Speed- blades only run on the "turtle" (slow) speed (all the way back)
- sometimes a little hard to get in place.
12. When done, shut off blades by pushing down yellow knob.